


SEARS 3-POINT HITCH - - MODEL NUMBERS 917.253050 AND 917.253060



SEARS 3-POINT HITCH - - MODEL NUMBERS 917.253050 AND 917.253060

KEY NO.	PART NO.	DESCRIPTION
1	120169	Cotter Pin 5/32 x 1
2	8924H	Lift Link, Upper – R.H.
3	1592H	Turnbuckle Spring
4	606A 108	Turnbuckle, Spring, and Roll Pin (Incl. Key No's. 3, 4 and 5)
5	9710M	Roll Pin
6	8923H	Lift Link, Lower – R.H.
7	5012H	Chain, Ring and Cotter
8	4940M	Retainer Spring
9	456723	Cotter Pin 3/16 x 1
10	5316H	Link Pin, Lower
11	634A290	Hitch Bar and Bushings, Lower
12	100147	Bolt, Hex 7/16 – 14 x 1¼
13	103328	Lockwasher 7/16
14	271501	Nut, Hex 7/16 - 14

15	-----	Model Plate Number
16	634A292	Hitch Mount Assembly with Lever (For Model Number 917.253050)
16	634A295	Hitch Mount Assembly with Lever (For Model Number 917.253060)
17	8940H	Clevis Pin
18	456122	Lockwasher ½
19	120426	Bolt, Hex ½ - 13 x 1¼
20	8936H	Clevis, L.H. Thread
21	8925H	Lift Link – L.H.
22	634A294	Adjusting Screw and Handle
23	121797	Bolt, Hex ¼ - 20 x 3/8
24	131098	Lockwasher ¼ heavy
25	8939H	Spring, Adjusting Screw
26	8935H	Clevis, R.H. Thread
---	8947H	Instruction and Parts Book